


## 2.5 Positioning the lights



Before each start-up, the lights must be positioned to illuminate the expected area of use.

### Positioning the wall/ceiling variants


- ☞ Move the lamp bodies into the desired position using the handle (1).

### Positioning the mobile variants

- ☞ Roll the unit with mobile stand (2) into the desired position.
- ☞ Apply the brakes for the individual casters (3). To do so, set the brakes using the lever (4).
- ☞ Move the lamp bodies into the desired position using the handle (1).


## 5.5 Dimension sheets

### 5.5.1 Ceiling variants




Variants with intermediate ceilings

## Technical data



Variants for raw ceilings

### 5.5.2 Wall variants



### 5.5.3 Mobile variants

